



# FR RAINWEAR SIZING GUIDES

P R O U D L Y M A N U F A C T U R I N G I N T H E U S A S I N C E 1 9 3 5

## RAINWEAR

### HYDROLite FR™ Storm Jacket / Bomber Jacket (HYDROJACK / HYDROBOMB)

Size	Chest	Sleeve Length*	Center Back Length
<b>SM</b>	33" - 37"	37"	HYDROJACK 35" all sizes
<b>MD</b>	37" - 41"	38"	
<b>LG</b>	41" - 45"	38.5"	
<b>XL</b>	45" - 49"	39.5"	HYDROBOMB 30" all sizes
<b>2X</b>	48" - 52"	40.5"	
<b>3X</b>	52" - 56"	41.5"	

\* Short: -3" off center back length & -1.5" off sleeve

\* Tall: +3" to center back length & + 1.5" to sleeve

### HYDROLite FR™ Bib Overall (HYDROBIB)

Size	Waist	Inseam*
<b>SM</b>	29" - 33"	28"
<b>MD</b>	33" - 37"	29"
<b>LG</b>	37" - 41"	30"
<b>XL</b>	41" - 45"	30"
<b>2X</b>	45" - 49"	30"
<b>3X</b>	49" - 53"	30"

\* Short: -2" off inseam

\* Tall: +2" to inseam

### HYDROLite FR™ Rain Pants (HYDROPANT)

Size	Waist	Inseam*
<b>SM</b>	32" - 35"	28"
<b>MD</b>	35" - 38"	29"
<b>LG</b>	38" - 41"	30"
<b>XL</b>	41" - 44"	30"
<b>2X</b>	44" - 47"	30"
<b>3X</b>	47" - 50"	30"

\* Short: -2" off inseam

\* Tall: +2" to inseam

### HYDROflash FR™ & Targo FR™ Jacket

Size	Neck	Chest	Arm Length - Regular
<b>SM</b>	14" - 14.5"	34" - 36"	31" - 31 3/4"
<b>MD</b>	15" - 15.5"	38" - 40"	32 1/4" - 33"
<b>LG</b>	16" - 16.5"	42" - 44"	33 1/2" - 34 1/4"
<b>XL</b>	17" - 17.5"	46" - 48"	34 3/4" - 35 1/2"
<b>2X</b>	18" - 18.5"	50" - 52"	36" - 36 3/4"
<b>3X</b>	19" - 19.5"	54" - 56"	37 1/4" - 38"

### HYDROflash FR™ & Targo FR™ Bib Overall

Size	Inseam - Regular	Waist
<b>SM</b>	32"	28" - 30"
<b>MD</b>	32"	32" - 34"
<b>LG</b>	32"	36" - 38"
<b>XL</b>	32"	40" - 42"
<b>2X</b>	32"	44" - 46"
<b>3X</b>	32"	48" - 50"

### Arc H2O™ FR Rain Jacket (R30) / Trench Coat (R31) & FR Contractor Jacket (J30)

Size	Chest	Sleeve Length*	Center Back Length
<b>SM</b>	34" - 37"	33.5"	R30 / J30 30.5" all sizes
<b>MD</b>	38" - 41"	34"	
<b>LG</b>	42" - 45"	34.5"	
<b>XL</b>	46" - 49"	35"	R31 48.5" all sizes
<b>2X</b>	50" - 53"	35.5"	
<b>3X</b>	54" - 57"	36"	

\* Short: -3" off center back length & -1.5" off sleeve

\* Tall: +3" to center back length & + 1.5" to sleeve

\* If your measurement is between sizes, it is recommended that the larger size be purchased.

## HOW TO MEASURE


**NECK**  
**A.** Measure around the base of the neck, where your collar typically lies. Measure from one button hole to the center of the button on the opposite side.

**CHEST**  
**B.** Measure around the fullest part of your chest. The best way to assess this is to start just under your armpit.

**WAIST**  
**C.** **For pants:** Measure around your waist where you would like you pants waistband to sit. **For tops & full body garments:** Measure the fullest part of your waist.

**SLEEVE**  
**D.** To measure your sleeve, start from the center of the back of your neck, over to your shoulder, down past your elbow, and to your wrist.

**INSEAM**  
**E.** Use a pair of pants similar to the style you are ordering, which fit to your liking. Measure along the inseam from the crotch to the hem.



**BUST**  
**A.** Measure loosely around the fullest part of your bust. Keep the measuring tape as horizontal as possible.

**WAIST**  
**B.** **For pants:** Measure around your waist where you would like you pants waistband to sit. **For tops & full body garments:** Measure the fullest part of your waist.

**HIP**  
**C.** Measure loosely around the fullest part of your hips. Keep the measuring tape as horizontal as possible.

**SLEEVE**  
**D.** To measure your sleeve, start from the center of the back of your neck, over to your shoulder, down past your elbow, and to your wrist.

**INSEAM**  
**E.** Use a pair of pants similar to the style you are ordering, which fit to your liking. Measure along the inseam from the crotch to the hem.